







Art. Nr. 89955060; 31164663; 47133609


LKZ 40947



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handlieding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |













№	Size/MaB (mm)	Qty	✓	№	Size/MaB (mm)	Qty	✓
1	968x420x24	1		13	1150x17x7	1	
2	1354x378x15	1		14	120x60x60	4	
3	1354x378x15	1		15	280x56x24	2	
4	879x367x15	1		16	807x56x24	1	
5	1354x56x18	1		17	807x56x15	1	
6	1354x56x18	1		18	803x182x18	1	
7	807x56x18	1		19	350x150x14	1	
8	879x74x15	1		20	773x150x14	1	
9	340x36x24	2		21	350x150x14	1	
10	878x366x15	2		22	782x342x3	1	
11	888x185x3	1		23	1107x400x18	1	
12	1163x443x3	2		24	1107x400x18	1	


1









2






3












4



5



6




5

7

H 27x10 160044
x2



N 250012 3.5x15
x4

P 250024 3.5x35
x4




8


B 030110
x6



9

B 030110
x12F 180074
x1N 250012
3.5x15
x2

10

B 030110
x4L 220043
x1S 080001
x6

J 030043
M4x10
x2

K b) x2
c) x2

Q 190002
x8

M 250004
3.0x13
x4

T 180080
x1

X 070045
Home
x1

U 090004
x1

V 250012
3.5x15
x1

W 250044
4x40
x1

