













Art. Nr. 87500542; 85461129; 24393663

LKZ 40947



- | | |
|---------------------------------------|------------------------------------|
| D Montageanleitung | GB Assembly instructions |
| FR Notice de montage | IT Istruzioni di montaggio |
| NL Handleiding voor de montage | PL Instrukcja montażu |
| CZ Montážní návod | SK Návod na montáž |
| HU Szerelési útmutató | RO Instrucțiunile de montaj |
| TR Montaj talimatı | RU Инструкция по монтажу |









Art. Nr. 87500542; Art. Nr. 85461129; Art. Nr. 24393663







	Size/MaB (mm)	Qty	✓	Nº	Size/MaB (mm)	Qty	✓
1	1028x92x994	1		3	2000x245x24	2	
2	1028x624x92	1		4	1980x35x24	2	

1








2

2



3



3