



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handlieding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180



A 030093
x50

B 030110
x50

C 230010
8x32
x32

D 030011
6.2/7.8x13
x8

E 210118
x2

F 030052
M4x22
x2

G 070017
30x30
x6

H 160005
x2

J 160005
x2

K 250024
3.5x35
x20

L 100072
x8

M 030033
7x50
x14

N 110021
SW4
x1

O 090004
8x40
x1

P 180080
76x31x15
x1

Q 250012
3,5x15
x1











R 250044
4x40
x1

2

A 030093
x30


C 230010
8x32
x22

G 070017
30x30
x2





3

B 030110
x4





4

B 030110
x6





5

B 030110
x4



6

B 030110 x16



7

A 030093 x4





B 030110 x4

C 230010 8x32 x4

E 210118 x2

F 030052 M4x22 x2

K 250024 3.5x35 x8



8

B 030110 x16

C 230010 8x32 x2

D 030011 6.2/7.8x13 x4






H 160005 x1

J 160005 x1

K 250024 3.5x35 x12

M 030033 7x50 x6

N 110021 SW4 x1



9

L 100072
x8

M 030033
7x50
x8











N 110021
SW4
x1

O 090004
8x40
x1

P 180080
76x31x15
x1

Q 250012
3,5x15
x1

R 250044
4x40
x1



Verriegeln / to lock

Entriegeln / to unlock